

ASSA ABLOY

Distributed lock controller EAC-TPE / EAC-TME

Installation guide

Contents

1. INTRODUCTION	4
Overview.....	4
Guarantee or warranty.....	4
2. WHAT IS IN THE BOX.....	5
EAC-TPE – carton contents.....	5
EAC-TME - carton contents.....	6
3. MOUNTING	7
Mounting the EAC-TPE	7
Mounting the EAC-TME.....	8
4. SITE MAPPING	9
5. PINOUT CONFIGURATION	10
Pinout and key components	10
6. DIP SWITCH SETTINGS	11
Controller MODE settings	11
Lock port settings	12
Reader port settings	12
7. DOOR WIRING.....	14
Wiring the relay terminals	14
Wiring snubber devices (warranty requirement)	14
Wiring solenoid locks	15
Wiring motor locks.....	16
8. READER WIRING	17
Wiring OSDP readers	17
Wiring Wiegand readers.....	18
9. CONTROLLER MODES	19
Device controller MODE.....	19
Fixed address handling capacity.....	19
RS485 wiring.....	19
Incedo Plus / Primo controller MODE	20
Offline operation	20
Fixed address handling capacity.....	20
Ethernet connection	20
RS485 wiring.....	20
10. NETWORKING THE CONTROLLER	21
Incedo Plus / Primo installations.....	21

11. COMMISSIONING.....	22
Powering up the EAC-TPE.....	22
Powering up the EAC-TME	23
<i>Optional gel battery</i>	23
Setting up the Incedo Plus / Primo controller	24
12. FACTORY RESET AND RTC.....	25
Factory reset	25
Real-time clock (RTC).....	25
13. SPECIFICATIONS.....	26
Working temperature range	26
Environment	26
Power supply requirements	26
Communication ports.....	26
<i>Ethernet port</i>	26
<i>RS485 port-1</i>	26
<i>RS485 port-2</i>	26
Power and status indicators.....	27
Power supply and tamper indicators	27
Ethernet indicators.....	27
RS485 indicators (1 & 2).....	27
Reader indicators (1 & 2).....	27
14. COPYRIGHT AND TRADEMARKS	28

1. Introduction

Overview

The EAC-TPE distributed lock controller provides all the control, communications, credential buffer and memory, digital inputs and relays required to serve up to two (OSDP) readers and an ASSA ABLOY electric lock (EL560, EL561, or EL520). The EAC-TPE and EAC-TME support OSDP and Wiegand readers.

The unit can be configured for different roles depending on the size of the installation and the location and required function:

- Device controller: As part of a small or large Electronic Access Control System (EAC)
- Stand-alone EAC system for small premises (via an integrated web application)
- System controller, as part of a large EAC (Incedo Plus / Primo software) able to control downstream device controllers, which could be other EAC-TPEs or other Incedo Plus / Primo hardware combos configured as device controllers

Models

This user guide covers the following models:

Model	Description
EAC-TPE	Stand-alone distributed lock controller with accessible terminals
EAC-TME	A distributed lock controller in a factory-wired steel cabinet with integrated AC mains adaptor, battery management PCB and space for a backup battery. Includes cabinet lid tamper sensing.


Guarantee or warranty

Three years, contact your regional ASSA ABLOY office for more information.


2. What is in the box

The distributed controller is offered in three different housing combinations – this section will tell you what you will find in the packaging for each model / housing combination.


EAC-TPE – carton contents



Distributed controller




Quick start guide




3 x Metal Oxide Varistors (MOVs)



3 x controller cover screws



Fixed address label




4 x jumpers


You will need:

- Basic electrical installation tools
- 12 V DC 2.5 A DC power supply to power this controller
- An auxiliary power supply to power the electric locks
- Cables for Ethernet, readers, door sensor inputs and relay loads
- Magnetic reed switches for Door Open Sensor (DOS)
- Push buttons for Request To Exit (RTE)
- Mag locks or strike locks
- Mounting hardware: Fasteners suitable for the mounting surface



EAC-TME - carton contents




Two door controller in a factory-wired steel cabinet with an integrated AC power adaptor
(Shown with the cabinet door removed)




Quick start guide




3 x Metal Oxide Varistors (MOVs)
2 x Crimp Lugs
4 x jumpers



4 x Cable ties, 2 x Cable tie cradles



Fixed address label
3 x lid screws



3 x mounting screws
and 8mm wall plugs

You will need


- Basic electrical installation tools.
- An AC supply cable to wire into the AC terminals (220V AC) on the factory installed DC/mains power adaptor.
- An auxiliary power supply to power the electric locks.
- Cables for Ethernet, readers, door sensor inputs and relay loads.
- Magnetic reed switches for Door Open Sensor (DOS).
- Push buttons for Request To Exit (RTE).
- Mag locks or strike locks.

3. Mounting


Choice of mounting location

- Choose a vibration free surface that is sheltered from the sun and the weather
- Allow for the routing requirements for the cabling

Mounting the EAC-TPE



1. Hold the EAC-TPE against the mounting surface (making sure to position it level) and mark the position of the mounting holes on the mounting surface, remove the EAC-TPE and drill the mounting holes
2. Secure the EAC-TPE to the mounting surface, using suitable screws and wall plugs or bolts and nuts (*note that the mounting holes in the controller have a diameter of 4 mm*)
3. Note the relevant door location and the fixed address of the controller – see [Site mapping](#)




1. Unplug the cabinet door earth strap
2. Unhook the door hinge lugs and remove the cabinet door.
3. Hold the cabinet against the mounting surface and mark the mounting hole locations.
4. Also mark the circular cable entry hole if you need to pass cables into (or through) the wall.
5. With the cabinet safely laid aside, drill the 8mm mounting holes and insert the included plastic wall plugs. Drill the cable entry hole in the wall, if needed.
6. Secure the cabinet to the mounting surface, using suitable screws and wall plugs.
7. Note the relevant door location and the fixed address of the controller – see [Site mapping](#).

4. Site mapping

Do the following for every controller that is installed:


- Apply the spare fixed address label for the controller to the quick start guide that is also included in the packaging
- Fill in a name for the door served by this controller – examples: Front reception, Goods receiving, Main gate, etc.



- Alternatively, you can print a plan, or sketch up a rough plan on a sheet of paper and apply the address labels to the plan
- Keep this site mapping material safe and available for use during the configuration of the access control software

5. Pinout configuration


Pinout and key components



6. DIP switch settings





NOTE:

The DIP switch settings (Reader 1, Reader 2 and MODE) are only read on power-up. Remember to cycle the power any time you make changes to these DIP switches.



Controller MODE settings

The controller can function as a device controller or as one of two system controller options:





MODE switches	Controller MODE	
0000 	Device controller MODE	
0110 		Application controller (APC) MODE Requires Incedo Plus / Primo Software running on a Windows PC
1XXX 		Factory default MODE On power-up this setting will default the controller Be sure to return the first switch to OFF after power-up

Lock port settings













Each of the two reader ports has a dedicated 4-way DIP switch to select the function of that port.

NOTE:










- ABLOY Electric Lock functionality is only available in [Door Controller mode](#)
- The Distributed lock controller lock port only has two valid settings when using ABLOY Electric Locks:

Lock switches	Lock port function	
2 		READER FOR ENTRY ONLY
5 		ENTRY and EXIT – must set Reader port for OSDP See Wiring OSDP readers on page <i>Error! Bookmark not defined.</i>

Reader port settings

Reader switches	Reader port function	
0 	Reader channel unused	
1 		Reader port is disabled The associated relay and digital inputs remain operative
2 	Not used	
3 	Not used	
4 	Not used	
5 	Not used	
6 	Not used	
7 		Wiegand 26, 32, 34, 35, 37, 38, 40, 42, 44, 48-bit, Tag + PIN code or Reason code mode
8 		Wiegand open format

This table is continued on the next page.

Reader switches		Reader port function	
9		Not used	
10		Not used	
11		Not used	
12		Not used	
13			OSDP reader – with parity <i>This option will NOT strip off any parity bits that are read from the tags</i>
14			OSDP reader – parity stripped <i>This option will strip off any parity bits that are read from the tags – it is the more commonly used option</i>
15		Not used	

7. Door wiring

Wiring the relay terminals

Relay contact specifications

Voltage	Maximum current
< 28 V DC	10 A

NOTE:

It is recommended that a separate power supply is used for the external loads.

AUX relay


The AUX relay is reserved for future functionality.

Wiring snubber devices (warranty requirement)


Snubber devices suppress sparking across the relay contacts caused by switching current to inductive loads, such as solenoid driven strike locks and mag locks. Failure to install suitable snubber devices will severely impact relay life and void the manufacturer's warranty.

NOTE:

Some locks include built-in snubber components, some don't. Whatever the case, it is advisable to install Metal Oxide Varistors (MOVs). Those included with the EAC-TPE are suitable for switching DC inductive loads up to 24 V.



The diagram below shows alternative snubber arrangements.



Wiring solenoid locks

The following ABLOY solenoid locks may be wired as indicated: EL-560, EL-561


Pin 14* must connect to either the SECURE OR SAFE terminal

- SECURE is the normally open relay terminal
- SAFE is the normally closed relay terminal

Select the required sense in the access control software.

Wire the lock cable to the distributed lock controller as per the table, as well as the **ground link**** mentioned below.

EL56X 14-way	Colour	Signal	EAC-TPE / EAC-TME Pin name
3	Green	N/C	
7	Black	N/C	
2	Yellow	Com-Yellow	COM-Y
5	Brown	Trigger	TRIGGER
6	White	Solenoid +12V	12VDC
9	Green/Red	Key Cylinder	CYLINDER
10	Orange	Bolt In	BOLT IN
11	Blue	Handle Down	HANDLE
12	Violet	Com-Violet	COM-V
1	Grey	Sabotage Loop	LOOP-GRY
4	Turquoise	Bolt Out	BOLT OUT
8	Pink	Sabotage Loop	LOOP-PINK
13	Yellow/Red	Com-Yellow/Red	COM-Y/R
14*	Red	Solenoid Ground	SECURE OR SAFE (Not both)



NOTE:


****Link** the PWR GND and GND terminals of the EAC-TPE.

Wiring motor locks

Motor locks require the EA420 interface unit installed between the distributed lock controller and the motor lock.

Wire EL520 motor lock to EA420 interface

EL520 motor lock Pin no	Lock cable colour	EA420 interface Pin no
1	Grey	31
2	Yellow	24
3	Green	23
4	Turquoise	30
5	Brown	26
6	White	21
7	Black	22
8	Pink	32
9	Green/Red	28
10	Orange	29
11	Blue	27
12	Violet	22
13	Yellow/Red	-
14	Red	25



Wire EA420 interface to the EAC-TPE


EA420 Interface Pin no	Signal	EAC-TPE / EAC-TME Lock terminal Pin name
1	Power +12V	12VDC
2	Power Gnd	GND
4	Common Door (Trigger)	COM-Y
5	Door Closed (Trigger)	TRIGGER
6	Handle Down	HANDLE
7	Common Handle	COM-V
9	Key Cylinder	CYLINDER
10	Common Cylinder	COM-V
12	Bolt In	BOLT IN
13	Common Bolt In	COM-Y
14	Bolt Out (Deadlocked)	BOLT OUT
15	Common Bolt Out	COM-Y/R
16	Opening	SECURE
18	Opening Gnd	PWR GND
31	Sabotage Loop	LOOP-GRY
32	Sabotage Loop	LOOP-PINK

8. Reader wiring

Wiring OSDP readers

NOTE:

OSDP readers should be powered from the 12 V output terminal provided only if the reader cable run is less than 150 m. Longer cable runs will require a 12 V DC supply within 150 m of the reader (and full spec RS485 cables). The 12 V terminal is internally fused and can supply up to 350 mA. The fuse will reset when current falls below the 350 mA threshold.



Maximum distances for OSDP

NOTE:

- It is recommended that OSDP cables any longer than 150 m should comply fully to the RS485 EIA/TIA standard
- If the reader cable length exceeds 150 m, a local 12 V DC power supply will be needed to power the OSDP reader. The volt drop across long cables would otherwise result in insufficient supply voltage at the reader

Cable length	Power source	Cable spec
Up to 150 m	+12 V from the controller	see reader manufacturers details
Up to 1000 m	Local DC power source	see reader manufacturers details

OSDP pairing (during commissioning)


- Set the reader to installation mode (referring to the reader's installation guide on how to do this)
- TOGGLE the first switch on the relevant two door controller reader port
- When the TX and RX LEDs for that reader port return to regular, rapid flashing, the reader is ready for use

Wiring Wiegand readers


The diagram below shows the connections for Wiegand readers. The coloured labels on the controller cover are included in the diagram for reference.

NOTE:


There are two DIP switch setting options for Wiegand readers.
The 12 V terminal is internally fused and can supply up to 350 mA. The fuse will reset when current falls below the 350 mA threshold.



Wiegand 26, 32, 34, 35, 37, 38, 40, 42, 44, 48-bit, Tag + PIN code or Reason code mode




Wiegand open format



Wiegand cable specifications

Application	Conductors	Max. length
Wiegand / Multi-discipline	See reader manufacturer's details	150 m (492 ft)


9. Controller MODES



Device controller MODE

Use this mode when this controller is part of an Incedo Plus / Primo system, where:

- The device controller is networked via IP
- OR via RS485 from another controller configured as an Incedo system controller



Set the controller MODE DIP switch settings to 0000 for device controller MODE

Fixed address handling capacity

As a device controller the controller only uses up a maximum of two fixed addresses.


RS485 wiring

Use the RS485-1 port for device controller networking.

Daisy-chain the connections and be sure to install the RS485-1 terminating jumper, only on the door controlling EAC-TPE that is the last controller in the chain.


NOTE:

The 12 V terminal is internally fused and can supply up to 350 mA. The fuse will reset when current falls below the 350 mA threshold.



Incedo Plus / Primo controller MODE

This system controller mode sets up the controller to be used in an Incedo Plus / Primo system, configured as a networked controller to control a maximum of 64 fixed addresses.



Set the controller MODE DIP switches to 0110 for Incedo Controller MODE

Offline operation

The controller will remember all credentials that have successfully accessed the doors that it controls. If the network connection is broken or lost, the controller will continue to allow access for those credentials.

Fixed address handling capacity

Incedo Controller MODE will allow the controller to handle up to 64 fixed addresses, including:

- Up to two addresses for the on-board reader interfaces
- Daisy-chained device controllers on RS485, with their reader port addresses contributing to a total no larger than 64

Ethernet connection


Connect the controller to the access control system computer via Ethernet.

RS485 wiring

Use the RS485-2 port to daisy-chain to any downstream device controllers. Be sure to connect the RS485-1 terminating jumper on the device controller that is most distant from the system controller.

NOTE:

Only connect the controller end of the RS485 screen to SHD, this will prevent ground loops.




10. Networking the controller

MODE settings for different locations in an installation

Incedo Plus / Primo installations

NOTE:

Device controllers in Incedo Plus / Primo installations can be daisy-chained to an Incedo system controller **OR** connected directly to an Ethernet switch, **OR** some to each – whatever is most practical for the site. Install RS485-2 jumper for most distant device controller on the RS485 daisy-chain. Only connect the controller end of the RS485 screen to SHD, this will prevent ground loops.



11. Commissioning

Before powering up:

- Check the wiring, making sure that any peripheral wiring, such as door sensors and locks, are correct and properly secured
- If controllers are linked with RS485, make sure that the most distant unit has the RS485-1 line termination jumper in place


Powering up the EAC-TPE

1. Wire the 12 V DC power supply to the 12 V DC terminal block on the controller
2. Remove the insulating tag from the button cell holder on the PCB
3. Connect equipment to AC power supply
4. Allow a minute for the controller to boot up and test both the RAM and flash checksums
5. When the controller passes the self-test, the red status LED will remain steadily illuminated as long the unit is powered up
6. Use a separate power supply to power up any loads that are switched using the onboard relays

NOTE:

*Always double-check your connection to ensure correct polarity on the controller's power terminals.
If any part of the self-test fails, the red status LED will keep flashing.*

If installing OSDP readers be sure to follow the three OSDP pairing steps on page 17.



Powering up the EAC-TME

1. Wire the 220V AC power cable to the AC power terminals on the power supply module inside the cabinet.
2. Remove the insulating tag from the button cell holder on the PCB.
3. Plug the mains cable into a mains outlet and switch it on.
4. Allow a minute for the Two door controller to boot up and test both the RAM and flash checksums.
5. When the unit passes the self-test, the red status LED will remain steadily illuminated as long the unit is powered up.
6. Use a separate power supply to power up any loads that are switched using the onboard relays.


Optional gel battery

Installing the recommended 12V gel battery will allow the Two door controller to continue normal operation in the event of a power outage. Connect the factory installed battery leads to the battery, observing the correct polarity.

The Battery Management PCB (mounted to the back of the tamper switch) includes a relay that will disconnect the battery to protect the battery from being ruined when its voltage falls below what is safe for the battery.

NOTE:

If you wish to power up the unit on the battery alone (on a healthy battery) you will need to engage the relay by momentarily shorting the two pins next to the relay. Do NOT leave this short in place, as it will prevent the relay from protecting the battery when it runs flat.





NOTE:

If any part of the self-test fails, the red status LED will keep flashing.

7. The access control software can now be configured:
 - [Incedo Plus / Primo](#)

Setting up the Incedo Plus / Primo controller

MODE:



This full-featured personnel access control system is offered with different license options suitable for sites ranging from medium to large, as well as enterprises that are located on multiple campuses any distance apart.

With the Incedo Plus / Primo software installed and running, log in, create the necessary user accounts, and use the options available to add and configure hardware. All functions include context sensitive help.

You will need any [site mapping information](#) that was gathered during the hardware installation.

Contact your regional ASSA ABLOY office for more assistance.

NOTE:

All Incedo controllers include spare fixed address labels that should be applied to a site map that you can refer to when allocating the hardware devices to their respective doors and areas.

13. Specifications

Working temperature range

–20 °C to +65 °C

Environment

Designed to work in an indoor (dry) environment (IP10), the controller is not sealed against water.

Power supply requirements

Input voltage range	12 to 15 V DC, polarity sensitive	
Power requirements	Current (mA)	Power (W)
12 V DC with no readers connected and relays off	20	0.24
12 V DC with maximum reader load and both relays energised	600	7.2

Communication ports

Ethernet port

Port type	Standard Ethernet RJ45 connector 10/100 Base T, half/full duplex
------------------	---

RS485 port-1

Purpose	This port is reserved for controlling Aperio wireless lock hubs
Electrical interface	RS485
Baud rate	19 200
Data format	8 bits, no parity, 1 stop bit
Communications protocol	Aperio communications protocol
Line termination (RS485)	Provision is made for line termination (jumper)

RS485 port-2

Purpose	This port is for networking Impro controller hardware
Electrical interface	RS485
Baud rate	38 400
Data format	8 bits, no parity, 1 stop bit
Communications protocol	Impro secure communications protocol
Line termination (RS485)	Provision is made for line termination (jumper)

Power and status indicators

LED indication	Meaning of the indication
Continuous red	Power is on
Intermittent flashing red	Device controller communications failure
Continuous flashing red	Controller fault

Power supply and tamper indicators

LED indication	Meaning of the indication
Red AC-FAIL LED on	AC power is down and the controller is running on battery
Red BAT LOW LED on	The battery is either flat or not connected
Red TAMP LED on	Open circuit across the tamper switch terminals

Ethernet indicators

LED indication	Meaning of the indication
Link LED continuous red	Ethernet is connected
SPD LED continuous red	Speed at 100 MHz
SPD LED OFF	Speed at 10 MHz

RS485 indicators (1 & 2)

LED indication	Meaning of the indication
Red TX LED on	Sending data
Green RX LED on	Receiving data

Reader indicators (1 & 2)

LED indication	Meaning of the indication
Red TX LED on	Sending data
Green RX LED on	Receiving data

14. Copyright and trademarks

Copyright

© 2025 ASSA ABLOY. All rights reserved.

This document may not be reproduced, disseminated, or republished in any form without the prior written permission of ASSA ABLOY.

Trademarks

Aperio is a registered trademark and is used under license.

Support

Visit www.assaabloy.com or contact your regional ASSA ABLOY office.

The ASSA ABLOY Group is the global leader in access solutions. Every day, we help billions of people experience a more open world.

ASSA ABLOY Opening Solutions leads the development within door openings and products for access solutions in homes, businesses and institutions. Our offering includes doors, door and window hardware, locks, access control and service.